



Racing Lane Modification Instructions

To set backstroke marker on lane:

1. Lay COMPETITOR[®] Racing lane on a flat surface.
2. Locate the 15M (49ft 2") from each end of the Racing lane – using a piece of masking tape, mark the disk you will be replacing. If it is next to a donut float go to the next closest disk.
3. Release all slack on the Take Up Reel, so that the Blue Nylon spool is showing.
4. Locate set-screw on Take Up Reel Spool and loosen.
5. Remove cable from Spool. Note the way the cable is threaded so re-attachment is done in the proper manner.
6. Carefully slide off all disks and donuts up to the marked location.
7. Remove disk with tape and slide new disk on in its' place.
8. Carefully reassemble pieces removed in the exact order.
9. Reattach hardware and repeat at other end of lane.
10. If you are using a convertible lane. You will repeat this operation for both lengths.

Manufactured by:
Competitor Swim Products
a Division of Richey Industries, Inc.
910 Lake Road
Medina, Ohio 44256

Tel: 330-725-4997 Fax: 330-722-3288 E-Mail: sales@competitorswim.com