

31" & 37" Pace Clocks

Assembly Instructions



 **Competitor**[®]

THE OFFICIAL
LANE LINE OF



THE OFFICIAL
LANE LINE OF

NCAA

CONGRATULATIONS ON PURCHASING YOUR NEW COMPETITOR PACE CLOCK.

Before you get started using this timing system for swimming, please use the following instructions to inspect your clock. We ship our clocks with pride and amazing inspection, sometimes during shipping, the clock will jostle.

BATTERY CLOCK

1. After you have removed your clock from the carton, place the battery inside the motor. Please be sure the on/off switch's wire (copper end) is sandwiched between the metal clip of the motor and the negative end of the battery.
2. Use the on/off switch to check that the on/off switch is working properly. If clock hands do not turn when you turn the clock on, you will need to adjust the copper piece. If the wire's copper end is not placed properly, the hands will continue to turn when the clock is turned off.



ELECTRIC CLOCK

1. Open the back cover plate and turn the small dial located on the motor clockwise - *turning counter-clockwise may cause a jam in the gears and prohibit your clock from working properly.*
2. Apply knurled nut onto the threaded oblong shaft and gently tighten until snug.
3. Once you have placed your clock in the desired location, you can turn your clock on by manually flipping the on/off switch on the cord of the clock.



Our clocks do not have an automatic reset. The second hand may be reset manually by opening the back cover plate and turning the small dial located on the motor.